

# Work Order ID 75752

**\*75752\***

Page 1

October-28-11 11:55:21 AM

Item ID: D206-642-113 Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: Stop **\*NS2\***  
 Item Name: Skidtube LH  
 Start Date: 28/10/2011 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 15/12/2011 Req'd Qty: 1.00 **\*1\*** Customer:  
 Reference:

Approvals: Process Plan: M.C.J Date: 11/10/28 Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start **\*NR1\***  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
IIN-D206-642	O

M.C.J 11/11/15

100 0.00

**\*100\*** DOCUMENT CONTROL  
 DC Memo 0.00 CHG001  
 Document Control Photocopy bluefile & type labels per PPP206-642-113-CHG001  
 K10111 CHG002 CHG003 Sizdoliz

110 0.00

**\*110\*** Pick Kit  
 Packaging Memo 0.00  
 Packaging Per 11/12

120 0.00

**\*120\*** QC4- 100% Inspect kits for completeness 0.00 Sizdoliz  
 QC Memo 0.00 (4)  
 Quality Control

**B76594LH**

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Work Order ID 75752

**\*75752\***

Page 2

October-28-11 11:55:21 AM

Item ID: D206-642-113 Accept **\*N900040100\*** Setup Start **\*NS1\***  
 Revision ID: Stop **\*NS2\***  
 Item Name: Skidtube LH  
 Start Date: 28/10/2011 Start Qty: 1.00 **\*1\*** Cust Item ID:  
 Required Date: 15/12/2011 Req'd Qty: 1.00 **\*1\*** Customer:

## Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_ Run Start **\*NR1\***  
 QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_ Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130 <b>*130*</b> Packaging	Packaging	0.00							
Packaging	Memo Identify and pack for shipping as per PPPD206-642-113 K10111 Location: <u>AK</u> PPP Rev: <u>AK</u>	0.00							
140 <b>*140*</b> QC Quality Control	QC21- Final Inspection - Work Order Release	0.00							
	Memo	0.00							

SP12-01-13.

12/11/16

MF  
12-01-13

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

October-28-11 11:55:25 AM

Page 1

Work Order ID: 75752

**\*75752\***

Parent Item: D206-642-113

**\*D206-642-113\***

Parent Item Name: Skidtube LH

Start Date: 28/10/2011

Required Date: 15/12/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV.N DD VERF:EC  
REV:B 11.09.23 ADDED K10111 DD VERF:EC

IPP

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D206-642-151		Manufactured	No			110	Each	0.0000	1	1			
<b>*D206-642-151*</b>									<b>**</b>				
Replacement Skidtube													
K10111 <i>CH1703</i>		Manufactured	No			110	Each	0.0000	1	1			
<b>*K10111*</b>									<b>**</b>				
Saddle, Skidtube 206													

*76 596*

*B-75864*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries